




2.4 M x 3.3 M / 8 FT x 11 FT Rectangle Height Adjustable Market Aluminum Umbrella

Assembly, Care & Use Manual

ITM. / ART. 1751977, 1768228

Model: #UMB-248110



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

For assistance with use, parts, or customer service, please contact:

ATleisure, LLC

Customer Service is available by email at customerservice@atleisure.com or
chat at <https://help.atleisure.com> 8 AM – 5 PM EST, Monday – Friday.

This item is intended for outdoor domestic use only. Not for commercial use.



Designed in USA



Contents

Package Contents

Assembly and Use

Care and Maintenance

Warning and Cautions

Replacement Parts

Warranty

Filing a Claim

2

3-5

6

6


6

7

7


Package Contents

Before beginning product assembly, completely inspect the umbrella and verify all parts are present. Lay out all contents on a clean, flat surface. Compare the parts with package contents list and diagrams below. If there is damage or any missing parts, do not (1) assemble umbrella (2) return to place of purchase. Customer Service is available by email at customerservice@atleisure.com or chat at <https://help.atleisure.com> 8 AM - 5 PM EST, Monday - Friday.




Part	Description	Quantity
A	Finial	1
B	Canopy	1
C	Umbrella Frame	1
D	Bottom Pole	1

Assembly and Use




Step 1: If not attached, align finial (A) to threading on top of umbrella frame (C) and turn clockwise (to right) to lock into place. Do not over-tighten.




Step 2: Insert upper pole into bottom pole (D). Then rotate the knob clockwise to lock in position.

Assembly and Use (cont.)




Step 3: Turn crank handle in clockwise direction (to right) until canopy is fully opened. Turn crank handle in opposite direction to close canopy and secure with attached strap.



Step 4: Insert umbrella into a heavy umbrella base no less than 50 lbs (not included). Tighten locking nut on side of base to safely secure umbrella.

Assembly and Use (cont.)



Step 5: To use the height adjustable function, rotate the knob clockwise to tighten into locked position. Rotate the knob counter clockwise to loosen and adjust the height.

NOTE: To prevent the pole from sliding too quickly and avoid risk of injury, hold the upper pole while adjusting the height. Stop raising the pole once you see 'MAX HEIGHT LIMIT' on the pole and then lock in position turning the knob clockwise until firmly stopped.

Care and Maintenance

See enclosed Outdura® care and cleaning label sewn into interior side of canopy.

Warnings and Cautions



DANGER: Keep children out of the assembly area during assembly.



WARNING: Read the entire instructions before beginning and follow the steps outlined. Failure to assemble and install as instructed could result in the umbrella tipping over, causing personal injury and/or property damage.



WARNING: Do not use this umbrella during periods of high winds and rain. Failure to do so may result in personal injury and/or damage.



CAUTION: Assemble and use umbrella on flat surfaces. Keep umbrella away from glass tabletops during windy conditions to prevent breakage.



INFORMATION: Recommend inserting the umbrella into an umbrella base (not included) to secure umbrella in upright position.




INFORMATION: Close the umbrella and use the canopy ties when umbrella is not in use.



INFORMATION: Schematics in this manual are for assembly and operation illustration only. They may differ from the umbrella's actual appearance.

Replacement Parts

Part	Description	Re-order No.
A	Finial	FNL-248110-A
B	Canopy - Ebby Ink, Myra Wheat	CAN-248110-B-EI CAN-248110-B-MW
D	Bottom Pole	BMP-248110-D



Warranty

This product is covered under a manufacturer's 2-year warranty from date of purchase against defects in materials and workmanship. This warranty does not cover damage due to neglect, abuse or weather related damage. For full warranty disclosure, email us at customerservice@atleisure.com or chat with us at <https://help.atleisure.com>

NOT COVERED UNDER WARRANTY

This warranty excludes the following: acts of nature (i.e. wind, fire, freezing); damage caused by improper assembly, accident, disaster, misuse, abuse, or negligence and discoloration or fading of the finish as a result of exposure to the elements. Product not intended for commercial use. This warranty gives you specific rights, and you may also have other rights which may vary from state to state.

AUSTRALIA: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be acceptable quality and the failure does not amount to a major failure.

Filing a Claim

If you are within your warranty, you may file a claim by sending your receipt and pictures of your damaged umbrella to ATLeisure at:

Email: customerservice@atleisure.com or chat with us at <https://help.atleisure.com> 8:00 AM to 5:00 PM EST (Monday - Friday)



www.atleisure.com
ATLANTA, GEORGIA, USA
Customer Service is available by email at
customerservice@atleisure.com or chat at
<https://help.atleisure.com> 8 AM – 5 PM EST, Monday – Friday.



2.4M x 3.3M / 8FT x 11FT
高さ調節可能なアルミ製
マーケットアンブレラ

組み立て、お手入れ、使用マニュアル

ITM. / ART. 1751977, 1768228

モデル: #UMB-248110

和訳



重要、将来の参照用に保管してください：
よくお読みください

使用、部品、カスタマーサービスに関するお問い合わせは下記まで：

ATLeisure, LLC

カスタマーサービスはメール (customerservice@atleisure.com) またはチャット
(<https://help.atleisure.com>) にて、月曜日から金曜日の午前8時～午後5時
(東部標準時)に対応いたします。

本製品は、家庭での屋外用のみを目的としています。業務用での使用は意図されていません。




設計: 米国

内容物


パッケージの内容物	2
組み立てと使用	3-5
お手入れ・メンテナンス	6
警告と注意事項	6
交換部品	6
品質保証	7
クレームの申請	7

パッケージの内容物


製品の組み立てを開始する前に、傘をよく点検し、全ての部品が揃っていることを確認してください。全ての部品を清潔で平らな場所に並べてください。部品とパッケージの内容物リストおよび下記の図を比較してください。破損や部品の欠品がある場合は、(1)傘は組み立てず、(2)購入店に返品してください。カスタマーサービスは、電子メール (customerservice@atleisure.com)またはチャット(<https://help.atleisure.com>)にて、月曜日から金曜日の午前8時～午後5時(米国東部標準時)までご利用いただけます。



部品	説明	数量
A	フィニアル(先端部)	1
B	キャノピー(天蓋)	1
C	傘フレーム	1
D	底部支柱	1




ステップ 1: 取り付けられていない場合は、フィニアル(A)を傘フレーム(C)上部の通し穴に合わせ、時計(右)回りに回して固定します。締めすぎないでください。




ステップ 2: 上部の支柱を下部の支柱(D)に差し込みます。次に、ノブを時計回りに回して位置を固定します。

組み立てと使用




ステップ 3: キャンピーが完全に開くまで、クランクハンドルを時計回り(右)に回します。反対方向に回してキャンピーを閉じ、付属のストラップで固定します。



ステップ 4: 重量23kg以上の重い傘ベースに傘を差し込みます(商品には含まれません)。ベースの側面にあるロックナットを締めて、傘を安全に固定します。

組み立てと使用



ステップ5: 高さ調節機能を使用するには、ノブを時計回りに回してロック位置に締めます。ノブを反時計回りに回して緩め、高さを調節します。

注: 支柱が急に滑り落ちてけがをする危険を避けるため、高さを調節する際は、上部の支柱を握ってください。支柱に「MAX HEIGHT LIMIT(高さの上限)」が見えたら、支柱を引き上げるのを止め、しっかりと止まるまでノブを時計回りに回し、位置を固定します。

お手入れ・メンテナンス

キャノピー内側についているOutdura®のお手入れとクリーニングのラベルをご参照ください

警告と注意事項



危険:組み立て中は、組み立て場所に子供を近づけないでください。



警告:組み立てを始める前に、説明書を全て読み、記載された手順に従ってください。説明書に従って組み立てや設置を行わないと、傘が転倒し、人身事故や物的損害を引き起こす可能性があります。



警告:強風や雨のときは、この傘を使用しないでください。これを守らないと、人身および/または物的損害を引き起こす可能性があります。



注意:傘は平らな場所で組み立ててご使用ください。強風の際は、破損を防ぐため、ガラス天板から傘を遠ざけておいてください。



ご案内:傘を直立した状態で固定するには、傘を傘立て(未付属)に差し込むことをお勧めします。




ご案内:傘を使用しないときは、傘を閉じてキャノピーの紐を使用してください。



ご案内:このマニュアルの図は、組み立てと操作の説明のみを目的としています。実際の傘の外観と異なる場合があります。

交換部品

部品	説明	再注文番号
A	フィニアル	FNL-248110-A
B	キャノピー - Ebby Ink, Myra Wheat (エビーインク、マイラウィート)	CAN-248110-B-EI CAN-248110-B-MW
D	底部支柱	BMP-248110-D



品質保証

この製品は、素材および製造上の欠陥に対し、購入日から2年間のメーカー保証の適用対象です。この保証は、不注意、乱用、または天候による損傷は対象外です。保証に関する全開示事項については、customerservice@at-leisure.com 宛てにEメールを送信するか、<https://help.atleisure.com>でチャットにてお問い合わせください。

保証適用の対象外

この保証は、以下の事項を対象外とします。自然現象(風、火災、凍結など); 不適切な組み立て、事故、災害、誤用、乱用、または怠慢による損傷、および風雨にさらされたことによる仕上げの変色や色あせ。本製品は業務使用を目的としていません。本保証はお客様に特定の権利を付与するものであり、お客様は州によって異なるその他の権利を有する場合があります。

クレームの申請

保証期間内であれば、レシートと破損した傘の写真を送付して、ATLeisure宛てにクレームを申請することができます。

Eメール:customerservice@atleisure.com またはチャットでのお問い合わせは
<https://help.atleisure.com> まで。米国東部標準時間 午前8時～午後5時(月曜日～金曜日)

Distributed by:
Costco Wholesale Corporation
P.O. Box 34535
Seattle, WA 98124-1535
USA
1-800-774-2678
www.costco.com

Costco Wholesale Canada Ltd.*
415 W. Hunt Club Road
Ottawa, Ontario
K2E 1C5, Canada
1-800-463-3783
www.costco.ca
* faisant affaire au Québec sous
le nom les Entrepôts Costco

Importado por:
Importadora Primex S.A. de C.V.
Blvd. Magnocentro No. 4
San Fernando La Herradura
Huixquilucan, Estado de México
C.P. 52765
RFC: IPR-930907-S70
(55)-5246-5500
www.costco.com.mx

Costco Wholesale Australia Pty Ltd
17-21 Parramatta Road
Lidcombe NSW 2141
Australia
www.costco.com.au

Costco Wholesale UK Ltd /
Costco Online UK Ltd
Hartspring Lane
Watford, Herts
WD25 8JS
United Kingdom
01923 213113
www.costco.co.uk

Costco Wholesale Spain S.L.U.
Poligono Empresarial Los Gavilanes
C/ Agustín de Betancourt, 17
28906 Getafe (Madrid) España
NIF: B86509460
900 111 155
www.costco.es

Costco Wholesale Iceland ehf.
Kauptún 3-7, 210 Gardabaer
Iceland
www.costco.is

Costco France
1 avenue de Bréhat
91140 Villebon-sur-Yvette
France
01 80 45 01 10
www.costco.fr

Costco Wholesale Japan Ltd.
2 Kakuchi, 2 Gaiku, Kaneda-Nishi
361 Urakura, Kisarazu shi
Chiba, 292-0007 Japan
0570-200-800
www.costco.co.jp

Costco Wholesale Korea, Ltd.
40, Iljik-ro
Gwangmyeong-si
Gyeonggi-do, 14347, Korea
1899-9900
www.costco.co.kr

Costco Wholesale New Zealand Limited
2 Gunton Drive
Westgate
Auckland 0814
New Zealand
www.costco.co.nz

Costco (China) Investment Co., Ltd.
Room 01 Mezzanine
No. 5178, Kang Xin Highway,
Pudong New District
Shanghai
China 201315
+86-21-6257-7065

Costco Wholesale Sweden AB
Box 614
114 11 Stockholm
Sweden
www.costco.se



www.atleisure.com
米国ジョージア州アトランタ
カスタマーサービスは、Eメール:
customerservice@atleisure.com または
チャット:<https://help.atleisure.com> にて受付可能。
午前8時～午後5時(米国東部標準時間)月曜日～金曜日