

# ANYWHERE SENSOR LIGHT BIG

## 取扱説明書

### ご使用上の注意

1. 本器は防雨構造ですが防水構造ではありません。屋外に取り付ける場合通常の雨には耐えますが、豪雨、台風等の大量の雨には耐えません。また長期間設置される場合は、直接雨の当たらない軒下等に取り付けてください。水が入り故障するおそれがあります。
2. 三脚で巻きつける場合は、本器が風等でふたつかないようにしっかりと巻きつけてください。センサーが誤動作して電池の消耗が早くなります。また落下の原因となります。
3. 取り付け場所は、もし落下しても安全な場所に取り付けてください。落下して事故や損傷のおそれがあります。また落下による機器の破損やトラブル等の一切の責任を負いかねます。
4. 取り付け場所は、カーテン、洗濯物、木、エアコンの室内外機、車の通り場所等の近くには取り付けしないでください。センサーが誤動作して電池の消耗が早くなります。
5. 単1型充電池（定格 1.2V）をご利用いただけますが、LEDの光が暗く感じたり、頻繁に充電しなければならぬ場合があります。
6. 風呂場等湿度の高い場所で使用しないでください。湿気が入り故障するおそれがあります。
7. LED 球を直視しないでください。目を傷めるおそれがあります。
8. 三脚の脚を同じ位置で繰り返し曲げないでください。折れるおそれがあります。

### 警告

1. 本製品は玩具ではありません。小さい部品が含まれていますので小さなお子様の近くで使用する際にはご注意ください。
2. 感電を防ぐため、水や水気の近くではご使用にならないでください。本体の掃除には、乾いた柔らかい布をお使いください。近くに水があり、落ちる可能性があるところへの取り付けはしないでください。
3. 感電を防ぐため、本体内部の部品は取り除かないでください。


### 注意

1. 適切な電池をお使いください（単1形アルカリ乾電池3本）
2. 古い電池と新しい電池を混ぜて使わないでください。違った種類の電池や使い古しの電池を混ぜて使うと、電池の液漏れや発火の危険があります。
3. アルカリ乾電池、マンガン乾電池、充電式電池（ニッケル水素電池）を混ぜて使わないでください。
4. 製品を長く、安全にお使い頂くため、電池は正しくお入れください。誤った使用法は、電池の発熱、液漏れ、爆発をまねくおそれがあります。けがの原因となりますのでおやめください。
5. 金属が電池取り付け接点部分へ触れないようにしてください。電池の発熱、液漏れ、爆発をまねくおそれがあります。
6. 電池の液漏れは、化学的熱傷を起こす可能性があります。液漏れしたものが肌など体についたら、ただちに流水で洗い流し、医師の診察を受けてください。
7. 長期間ご使用にならない場合は、本体から電池を抜いてください。

### 使用方法


#### ●点灯時間切替スイッチ

- OFF** 電源を切ります。  
周囲が暗い時に人が来ると、センサーが反応し自動点灯します。
- 10s** 人がいなくなると、10秒後に消灯します。
- 30s** 人がいなくなると、30秒後に消灯します。
- ON** スイッチの入っている間点灯します。



#### ●明るさ切替スイッチ

- 弱 / 中 / 強の3段階の明るさを選択できます。  
スイッチを左側へ切り替えるほど、明るさが明るくなります。



# ANYWHERE SENSOR LIGHT BIG

## OPERATING MANUAL

### SAFETY RULES

1. This product is rainproof, NOT waterproof. Buckets of rain or storm causes problems. If you will use it for a long time, install it where the body is not exposed to the rain. Otherwise, water might come in the body and cause malfunction.
2. Install the body firmly NOT to wobble when you attach with the tripod. The sensor might work improperly and battery life will be short. Also it may cause of drop.
3. Install the body where it will NOT cause any accidents even if it fell. This warranty DOES NOT cover any damage or troubles caused by dropping it.
4. DO NOT install the sensor light near curtains, trees, indoor/outdoor machines of air conditioner and the place where cars go through. The sensor might work improperly and battery life will be short.
5. Rechargeable D batteries (rated 1.2V) can be used. The light may be darker than using alkaline batteries or may need to charge batteries frequently.
6. DO NOT use the product in a bathroom or any other humid places. Damp may cause malfunction.
7. DO NOT look LED bulbs directly. It may injure your eyes.
8. DO NOT bend the tripod many times at the same point. It will snap off.

### WARNING

1. This product is not a toy and contains small parts. Close supervision is necessary when this product is used near children.
2. To reduce the risk of electrical shock, do not put the product in water or other liquid. For cleaning, use a soft dry cloth. Do not place or store appliance where it can fall or be pulled into a tub or sink.
3. To reduce the risk of electric shock, do not remove any enclosed parts.


### CAUTION

1. Use only proper size and type of batteries. (3 D alkaline batteries are recommended.)
2. DO NOT mix old and new batteries. Using mixed batteries may cause of leak or explosion.
3. DO NOT mix alkaline, carbon zinc or rechargeable(NiMH) batteries.
4. Batteries must be inserted in correctly for continued safe and proper use. Improper use or insertion may cause batteries to heat up, leak or explode, which may be harmful or cause injury.
5. DO NOT allow any metallic materials to touch the battery compartment contacts. Such contact may cause batteries to heat up, leak or explode.
6. Battery leaks can cause chemical burns. If leakage occurs and comes in contact with skin or anywhere on the body, immediately flush with water (NOT HOT) and examined by a doctor.
7. Remove batteries during long-term storage.

### HOW TO USE


#### ● LIGHT TIMER SWITCH

- OFF** Turn OFF the power.  
If a person comes while the surroundings are dark, the motion sensor reacts to light up automatically.  
\*If the surroundings are bright with other lighting even at night, it does not light up.  
\*If person's movement is small, it will be OFF in setting times.
- 10s** If a person has gone, it lights off after about 10 seconds.
- 30s** If a person has gone, it lights off after about 30 seconds.
- ON** It lights while the switch is ON.




#### ● BRIGHTNESS

- 3 stages. (Low / Middle / High)  
Move the switch to the left to make the brightness brighter.



## 部位説明


### ① 本体



### ② 三脚



### ③ 付属




### ④ 電池

単1形アルカリ乾電池 3本 (別売)

- ① 本体：アームの回転軸で 360 度回転します。アーム底部のマグネットで、付属のマグネット取り付け用プレートや鉄材に貼り付けられます。
- ② 三脚：アーム底部の三脚用ネジ穴にねじ込み使用します。
- ③ 付属：マグネット取り付け用プレートは木材の壁等にプレート用取り付けネジで取り付けます。コンクリート用プラグはコンクリートの壁とマグネット取り付け用プレートの取り付けに使用します。  
※ 木材の壁は 3mm、コンクリート用プラグを挿入するには 6mm の下穴をドリルで開けてから取り付けネジを締め込んでください。

## 電池の交換方法

1. ライト部の突起ラインを、OPEN の突起ラインまで回転させ (図 1)、手前に引いて電池蓋を外します (図 2)。
2. 新しい単1形アルカリ乾電池3本 (別売) を中極、⊖極を正しく合わせ取り付けます。
3. ライト部の突起ラインを OPEN の突起ラインに合わせてから電池蓋を押し込み、CLOSE の突起ラインに重なるまで回転させて、しっかり閉じます。  
※必ず3本共に同じ種類の新しい単1形アルカリ乾電池を使用してください。



## 保証

この製品は優れた技術と部品で製造され、厳密な検査をへて出荷されたことを証明し、下記の規約により小売店から購入した日から6ヶ月間、その品質を保証します。

1. 通常使用により欠陥が生じた場合は、無償で新品と交換または修理いたします。ただし、以下の理由は免責といたします。
  - ① 取扱上の不注意、誤った使用方法。
  - ② 天災・火災等。
  - ③ お買上げ後の輸送・移動・落下等。
  - ④ 保存上の不備。
  - ⑤ 小社以外による修理または改造。
  - ⑥ 本製品本来の使用目的以外の使用。
2. 使用に伴う部品の消耗には保証の適用はされません。
3. 運送料および梱包料等の費用は、お客様でご負担ください。  
※販売店名、ご購入年月日のないものは無効となります。
4. 保証期間が切れた後の修理、保証の適用されない故障につきましては、有償で修理いたします。
5. 一切の工事費用は、お客様の負担となります。
6. 本証は、再発行いたしません。

商品の組み立て、取り付け、部品のお問い合わせなどについては小社のお客様相談窓口までご連絡ください。

TEL 050-3643-0733

NINGBO LAITING INTERNATIONAL TRADE CO.,LTD.


1st Floor Building 1, No.8 Hongda Road, Jiangbei District, Ningbo, China

|        |                           |     |   |
|--------|---------------------------|-----|---|
| 購入品名   | ANYWHERE SENSOR LIGHT BIG |     |   |
| 購入年月日  | 年                         | 月   | 日 |
| 住所 (〒) |                           |     |   |
| TEL    | 名前                        | (印) |   |
| 販売店名   | 故障状況                      |     |   |

上欄に記入または捺印の無い場合は、必ず販売店様発行の領収書など、ご購入年月日、店名などを証明するものを貼ってください。

## DESCRIPTION OF PARTS


### ① BODY



### ② TRIPOD



### ③ ACCESSORIES




### ④ BATTERY

3 D alkaline batteries (not included)

1. BODY : Multi-directional head swivels 360°. Mounts on magnet plate or iron materials with magnet of the bottom.
2. TRIPOD : Install to tripod socket hole.
3. ACCESSORIES : Magnet plate should be mounted on a wooden wall with plate mounting screw.  
Use concrete plug to mount magnet plate on a concrete wall.  
\* Need to drill 3mm pilot hole on a wooden wall, 6mm pilot hole for concrete plug.

## HOW TO REPLACE BATTERIES

1. Turn the battery cover to the "OPEN" and pull it away to remove the battery cover. (Fig.1, 2)
2. Insert D batteries. Be sure to align the positive(+) and negative(-) terminals correctly. (Batteries are not included)
3. Match the "OPEN" of the main body and the cover, then push the battery cover. Turn the battery cover to the "CLOSE" to the mark and close.  
\* Use new batteries of the same type for all 3 batteries.



## WARRANTY

This warranty shows that this sensor light is made with high quality parts and superior technology, and passed the strict inspection. We guarantee the quality of the product for 6 months from the date of original purchase.

1. The item will be exchanged for a new one for free if malfunction in the materials or in the assembling process occurs during normal use, EXCEPT situations below.
  - ① Improper use, mishandling
  - ② Transporting, moving or dropping after purchase
  - ③ Natural disasters, fire
  - ④ Improper storing
  - ⑤ Repairing or modifying by unauthorized people
  - ⑥ Used inappropriate way
2. The warranty DOES NOT cover parts damaged due to normal ware.
3. Customers are responsible for all postage costs on returned merchandise.  
\* NOTE : Warranty is effective only upon presentation of dated proof of purchase.
4. Customers are liable for the cost of repairs after expiration of warranty or damage out of warranty.
5. All construction costs are to paid by customer.

For assistance with assembly or installation, parts and customer service, please contact us to our customer support center.

TEL 050-3643-0733

NINGBO LAITING INTERNATIONAL TRADE CO.,LTD.

1st Floor Building 1, No.8 Hongda Road, Jiangbei District, Ningbo, China

## LIMITATIONS ON WARRANTY DISCLAIMERS

There are no warranties which extend beyond the description on the face hereof.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.